

**READ BEFORE INSTALLATION**

The use of any Rennline product is the sole responsibility of the end user. Rennline Inc. Accepts no responsibility for warranty voids or damage resulting from the use of these products. Due to the varying location of wiring harnesses and other components, carefully inspect any area prior to drilling. All Rennline products are intended for off road use and should be installed by a qualified automotive technician.

**Rear Toe Control Arm W/Bump Steer - Bushing Kit**

**996/997/986/987/Cayman**

Check to make sure that you have all parts listed prior to installation.

**Parts List:**

- (3) P/N S03 Bushing
- (1) P/N S43 Bushing
- (1) P/N S42 Bushing
- (1) M12x90mm Bolt MC91310A740
- (1) M12x1.75 Nut MC98498A100
- (8) M12 Washer MC98035A107

**Step 1 - Remove factory toe control arm**

**Step 2 - Install Rennline adjustable arms as shown below, apply anti seize or equivalent to the threads of the aluminum tube.**

**Step 3 - Torque bolts to 75 ft-lbs.**

**Step 4 - Align car**

