



EN) EMERGENCY HAMMER

PRODUCT DESCRIPTION

- A** POWERFUL, STEEL HAMMER HEAD/WINDOW BREAKER
- B** RAZOR SHARP SAFETY BLADE/SEATBELT CUTTER
- C** FLUORESCENT ERGONOMIC HANDLE/STURDY GRIP
- D** INCLUDES A STURDY BRACKET WHICH ATTACHES TO THE DASHBOARD, CONSOLE, OR SIDE PANELS FOR QUICK ACCESSIBILITY/EASY TO INSTALL

INSTALLATION INSTRUCTIONS

EASILY ADHERES TO ANY HARD SURFACE SUCH AS THE DASHBOARD, CENTER CONSOLE, FRONT INTERIOR PANEL, ETC.

1. LOCATE A CONVENIENT, VISIBLE AND EASY TO ACCESS HARD SURFACE IN YOUR VEHICLE TO MOUNT THE BRACKET
2. CLEAN AND WIPE THE SURFACE WHERE YOU PLAN TO MOUNT THE BRACKET, LET DRY
3. REMOVE THE RESQHAMMER™ FROM THE BRACKET
4. PLACE ONE DOUBLE SIDED TAPE PROVIDED ON EACH END OF THE BACKSIDE OF THE BRACKET
5. ADHERE THE BRACKET TO THE CLEANED AREA
6. LET DRY FOR 24 HOURS BEFORE REMOUNTING THE RESQHAMMER
7. DO NOT DRILL INTO THE CAR TO INSTALL THE MOUNT UNLESS PERFORMED BY A PROFESSIONAL

WARNING: BRACKET SHOULD BE PLACED IN AN AREA THAT BOTH THE DRIVER AND FRONT PASSENGER CAN REACH. RESQHAMMER SHOULD ALWAYS BE MOUNTED TO ENSURE ACCESS IN CASE OF EMERGENCY. NEVER LEAVE RESQHAMMER IN YOUR GLOVE COMPARTMENT OR TRUNK. RESQHAMMER IS FOR EMERGENCY USE ONLY. IF YOU WANT TO TEST RESQHAMMER, WEAR GLOVES AND GOGGLES. FOR USE ON TEMPERED GLASS ONLY. DOES NOT WORK ON WINDSHIELDS. SOME AUTOMOTIVE SIDE WINDOWS ARE LAMINATED: ASK YOUR CAR DEALER FOR MORE INFORMATION.

KEEP OUT OF REACH OF CHILDREN

E OPTIONAL SNAP IN FOR RESQME® TOOL OR LED RESQLITE™.

SIMPLY REMOVE CLIP AT BOTTOM OF RESQHAMMER™ WITH HELP OF PLIERS, AND SNAP IN THE RESQME TOOL OR LED RESQLITE FOR ADDED TOOL SAFETY FEATURES.