



**INSTALLATION INSTRUCTIONS FOR 2007-2014
CHEVY 1500 PICKUP/ TAHOE/AVALANCHE/SUBURBAN/2 & 4WD
GMC 1500 PICKUP/ YUKON/CADILLAC/2 & 4WD
DIFFERENTIAL DROP KIT RTDD5-KB**

DISASSEMBLY AND ASSEMBLY OF DIFF DROP KIT

1. Remove the 2 diff bolts on driver side differential that attach the diff housing to the frame mount. Install diff spacers (P/N C3DB) using new M12 X 1.75 X 50 bolts. This is to space the diff down 1/2" to improve the angle on the CV boots. See Fig. A
2. Repeat this process on the passenger side of the vehicle. Remove the 2 OEM diff nuts on passenger side differential that attach the housing to the frame. Install diff spacers (P/N C3DA) utilizing the supplied M12 x 1.75 nylon locking nuts. See Fig. B



Fig. A



Fig. B