

Installation Instructions



Part # 11379300 - 1988-1998 C1500 HD Drop Spindles



Recommended Tools





1988-1998 C1500 Drop Spindles Installation Instructions

Installation

Torque Specs:

Splash Shield to Spindle: Upper Balljoint: Lower Balljoint: Outer Tie Rod: 19 ftlbs74 ft lbs and then tighten nut to align cotter pin.94 ft lbs and then tighten nut to align cotter pin.46 ftlbs and then tighten nut to align cotter pin.

THESE SPINDLES ARE DESIGNED FOR THE HEAVY DUTY BRAKES, 1 1/4" THICK ROTORS.