



Part # 11069000
59-64 Chevy Impala Panhard Bar Kit

Components:

| | | |
|---|----------|---|
| 1 | 90000993 | Panhard bar |
| 1 | 90001942 | Rubber bushing – pressed into panhard bar |
| 1 | 90001946 | Panhard Kevlar lined Heim end – 3/4" I.D. |
| 2 | 90000460 | Aluminum T bushing – for heim end |
| 1 | 90001946 | Panhard bar rod end |
| 1 | 90000461 | Panhard bar stud |

Hardware:

| | | | |
|---|----------|------------------------------|----------------------|
| 2 | 99603003 | 5/8" USS flat washer | Panhard bar stud |
| 1 | 99563001 | 9/16" USS flat washer | Panhard bar stud |
| 1 | 99561001 | 9/16" x 2 1/2" SAE Gr.8 bolt | Panhard bar to frame |
| 2 | 99562001 | 9/16" SAE Nylok nut | Panhard bar |
| 1 | 99752004 | 3/4"-16 Jam nut | Heim ends |
| 1 | 99622006 | 5/8" SAE Nylok jam nut | Pan hard bar stud |

Installation Instructions



1. Install the $\frac{3}{4}$ " jam nut onto the end of the Heim end, then screw Heim end into the end of the panhard bar.
2. Press the aluminum T-bushings into the Heim end. Fasten the Heim end to the frame bracket using the $\frac{9}{16}$ " x $2\frac{1}{2}$ " bolt and Nylok nut supplied.



3. Bolt the new panhard bar stud onto the axle in factory stud location using the $\frac{9}{16}$ " Nylok nut and flat washer supplied.
4. Slide the rubber end of the panhard bar onto the stud and secure with $\frac{5}{8}$ " thin Nylok nut and flat washer.