

RKSPORT



Installation instructions for RKSport Part #'s 26012004-26012005 Solstice [Rear Exhaust Filler](#)

1. Jack rear of vehicle and support with jack stands.
2. Remove rear wheels.
3. Remove rear bumper from vehicle. (You will need to remove rear tail lights to expose all hardware.)
4. Remove lower filler from bumper.
5. Install Carbon Fiber filler to stock bumper by inserting metal tabs into the bumper slots and bending the metal tabs to secure it to the bumper.
6. Using a 1/4" drill bit drill 2 holes on the bottom edge of the carbon panel and through the bumper. Then place the plastic fastener into the holes.
7. Replace rear bumper to car using all OE hardware.