

INSTUCTIONS FOR THE INTAKE/AIR INDUCTION KIT FOR RKSPORT'S '93-'97 CAMARO FUNCTIONAL RAM-AIR COMP HOOD

- Complete intake up to mass air sensor must be removed including filter box.
- Remove two front bolts on fuel rail.
- Remove clip for fuel lines from throttle body cover.
- Remove the rubber 90 degree elbow from the air tube that goes into the headers
- Loosen the air tube from where it goes into the header
- Rotate the air tube 180 degrees back towards the fire wall and then bend slightly down toward the headers (This is for clearance purposes only)
- Bend tube from air pump towards the driver's side wheel well as far as possible so as to clear the installation of the new air box
- Install the rubber tube provided in your kit by connecting the metal tube from the air pump to the diaphragm that you previously rotated 180 degrees
- To install the air box, you may want to cut (2-3) billows from the rubber elbow connected to the throttle body. This will make the installation process easier.
- The air box tube fits directly to the mass air sensor
- The fuel lines will run over the top of the air tube