



**Installation Instructions for the California Dream Mustang**  
**Wing Part #18013010**

1. Always pre-fit parts to vehicle prior to painting.
2. Remove stock wing from vehicle.
3. Put “T-Straps” in bolt holes of center section of the wing and place on your vehicle. Secure the “T-Straps” to your vehicle using masking tape to that they will stay on the vehicle as you remove the part from the vehicle.
4. Using a 1/8<sup>th</sup> “ inch drill bit, drill through the pilot holes of the “T-Strap”.
5. Remove “T-Straps” and drill 1/4 “ inch holes.
6. Mount wing to the trunk lid.
7. Replace brake light in the wing.
8. To mount the “ears”, use the same method as above.

**Hardware:**

- (4) – “T-Straps”
- (3) – 1/4 “X20X1/2” Panhead bolts
- 94) – 1/4 “X20X1/2” Hex Bolts