



## Installation of C5 RK Sport Hood

Thank you for choosing a quality product for RK Sport. Our desire is to give you another reason to enjoy your Corvette even more.

A few simple steps will insure you of an easier installation.

1. Prior to removing your stock hood, check carefully the alignment of all gaps and surface matches to fenders, front fascia and head lamp covers.
2. Disconnect trouble light at connector located at right front.
3. Remove clips on hood support shocks with a flat screwdriver.
4. Remove the (4) nuts that attach hood hinges to frame of car.
5. Now you can remove the hood from the vehicle and place it on a protected area, so as not to scratch the paint, with underside of hood facing up so that you can remove all the hardware.
6. **IMPORTANT**  
Prior to installing any hardware on the new hood, place the new hood into position on the car to make sure all alignments are correct. You may need to support the hood from underneath.
7. Remove all hardware from stock hood.  
DO NOT install on new hood until.
  - A. For adjustment purposes we suggest further elongating the rear hinge (Fig. A) attachment hole (this is the hole that is already elongated and attaches to the hood, not the frame) so that the hinge can be adjusted closer to the top of the hood.
8. Attach hinges, light, inner pad, and support brackets only. Do Not install latches until you have done final adjustments.
9. Place hood on car and make your adjustments.
10. Now place the latching hardware on hood and adjust latches, that are attached to the quarter panels (3 bolts) for proper alignment and closing height.