



INSTALL INSTRUCTIONS

Jeep JK Front Fenders

Product : JK100, JK100F

Application : 2007+ Jeep Wrangler JK

2 Door and 4 Door

I WARNING

Read the instructions completely before beginning installation. Before tightening bolts, drilling or cutting where required, check to make sure there are no obstructions such as brake, fuel or electrical lines which may be damaged. Also keep in mind this is an after-market product and **MAY** require minor shimming and/or trimming, reaming, etc. for proper fit.

i IMPORTANT NOTICE

If you are receiving this Road Armor product raw/uncoated :

- Be sure to inspect and test fit your product to ensure proper fitment before having it coated, painted, bed lined, etc.
- Road Armor will not be responsible for the cost of coating your unit if any problems with fit or finish are not noted and addressed beforehand.

SAFETY FIRST!

- FOLLOW ALL INSTRUCTIONS, YOUR SAFETY AND THE SAFETY OF OTHERS IS VERY IMPORTANT.
- WEAR APPROPRIATE EYE PROTECTION AND EXERCISE CAUTION WHEN DRILLING / CUTTING

REQUIRED TOOLS

- 1) Metric and SAE Socket Sets and Wrenches
- 3) T27 Bit Socket
- Spot Weld Drill Bit, or 1/4" Drill Bit

- 2) Pry Bar or Large Flathead Screwdriver
- 5/16" Allen Wrench or Hex Bit Socket
- Rust Inhibiting Spray Paint

INCLUDED HARDWARE

- (4) #10-24 x 3/4-in Button Head Screws

- (4) #10 Keps Lock Nuts









