Metric-to-standard brake line tee

Use the 7921 brake line tee to install the BrakeMaster 9060 proportioning valve in motorhomes with M12 x 1 metric brake lines. For many applications, the brake line tee may be attached as shown below – at the junction of the steel brake line to a rubber brake hose.



Do not install the brake line tee, or any component of the BrakeMaster supplemental braking system, without reading the complete installation instructions.

Failure to understand how to install or operate the BrakeMaster system could result in property damage, personal injury or even death.



