



Ultimate Fit / Big Mudder™ [Splashguards](#): Truck Application Guide

Model	Year	Regular Series		Big Mudder	
		Pt # Front	Pt # Rear	Pt # Front	Pt # Rear
Chevrolet/GMC					
Blazer K (Full Size)	1992-98	2022	2023	3103**	3103**
CK, Sierra (Pickup) w/o Flares	1988-89	2022	2023	3103**	3103**
CK, Sierra (Pickup) w/ Flares	1988-98	2101	2102	2201	2202
Silverado/Sierra w/o Flares P/U ³	1999-06	2103	2104	2203	2204
Silverado/Sierra w/o Flares Dually ³	1999-06	2103	3104**	2203	3104**
Silverado/Sierra w/ Flares P/U ³	1999-06	2105	2106	2205	2206
Silverado/Sierra w/ Flares Dually ³	1999-06	2105	3104**	2205	3104**
Suburban, Yukon, Tahoe w/o Flares	1992-99	2022	2023	3103**	3103**
Suburban, Yukon, Tahoe w/ Flares	1992-99	2101	2102	2201	2202
Suburban, Yukon, Tahoe w/o Flares ³	2000-06	2103	2104	2203	2204
Suburban, Yukon, Tahoe w/ Flares ³	2000-06	2105	2106	2205	2206
S10/S15, Sonoma Pickup	1982-93	2036	2037	3102**	3102**
S10/S15, Sonoma Pickup ¹	1994-04	2032	2033	3102**	3102**
S10/Sonoma Pickup	1994-04	-	2111	3102**	3102**
S10 Blazer/Jimmy	1983-94	2036	2037	3102**	3102**
S10 Blazer/Jimmy ¹	1995-97	2032	2033	3102**	3102**
S10 Blazer LS/LT Jimmy SLS 2 & 4Dr. ²	1995-03	-	-	3102**	3102**
S10 Blazer LS/LT Jimmy SLS 2 & 4Dr. ²	1998-03	-	2109	3102**	3102**
<i>1: Part #2032 & 2033 fit base vehicle only w/o plastic flares & stainless trim 2: Part #2108 & 2109 fit vehicles w/o plastic flares 3: Part #2103 & 2105 fit vehicles w/o running boards</i>					
Dodge/Plymouth					
Durango with or w/o flares	1998-03	-	2115	3102**	3102**
Ram Pickup 1500	1994-01	2117	2117	2217	2217
Ram Pickup 1500	2002-06	2136	2137	2236	2237
Ram Pickup 2500, 3500	1994-02	2117	2117	2217	2217
Ram Pickup 2500, 3500 Dually	1994-02	2117	3104**	2217	3104**
Ram Pickup 1500/2500/3500	2003-08	2136	2137	2236	2237
Ram Pickup 2500, 3500 Dually	2003-09	2136	-	2236	3104**
Ram Pickup 1500/2500/3500 Dually	2003-08	2136	3104**	2236	3104**
Caravan Voyager SE (rear application 1991-95)	1989-95	2034	2035	-	-
Note: Part #2034 does not fit LE, ES, Sport Wagon or Town & Country models					
Ford					
Excursion XLT w/o flares	2000-04	2128	2129	2228	2229
Excursion Limited w/o flares	2000-04	2129	2129	2229	2229
Expedition XLT w/o running boards/step bar	1998-02	2048	-	3103**	3103**
Explorer w/o running boards	1993-96	2024	-	3102**	3102**
Explorer	1991-94	-	2025	3102**	3102**

F Series Pickup ⁴	1987-96	2026	2027	3103**	3103**
F150 Pickup w/ or w/o flares & 04 Heritage	1997-04	2048	2049	3103**	3103**
F150 Pickup w/o Flares	2004-10	2132 ⁵	2133 ⁵	2232 ⁵	2233 ⁵
F150 Pickup with Flares	2004-10	2130 ⁵	2131 ⁵	2230 ⁵	2231 ⁵
F250/350 Super Duty (except Dually)	1999-10	2128	2129	2228	2229
F250/350 Super Duty Dually	1999-10	2128	3104**	2228	3104**
Ranger Pickup w/o Flares	1993-98	2028	-	3102**	3102**
Villager (rear application 1993-95)	1993-99	2040	2041	-	-

4: Parts #2026 & 2027 not fit 1992 & newer flareside or wheel vehicles.

5: Parts #2130, #2131, #2132, #2133, #2230, #2231, #2232 and #2233 do not fit 2004 Heritage model

Honda					
Ridgeline	ALL	-	-	3102**	3102**
Jeep					
Grand Cherokee Limited & Overland (rear only)	1999-03	2126	2127	3102**	3102**
Nissan					
Frontier	ALL	-	-	3102**	3102**
Titan	ALL	-	-	-	-
Toyota					
Tacoma Pickup	1996-06	-	-	3102**	3102**
Tundra Pickup	ALL	-	-	3102**	3102**

****** #3102, #3103, and #3104 are DiamondPlate design, rubber, and flat molded for universal fit to which #3101 Stainless Steel accents can be added.

#3102 is 17.5"L x 10"W

#3103 is 20"L x 12"W

#3104 is 20"L x 22.5"W