



**ROCK HARD 4X4 REAR LOWER CONTROL ARM SKIDS FOR  
JEEP TJ/LJ 1997 - 2006  
PART #: RH-9033  
Installation Manual**



Thank you for your purchase! Please read all instructions carefully prior to beginning installation of your Rock Hard 4x4 product.

**PACKING LIST:**

- 2 - CONTROL ARM SKIDS
- 2 - BOLTS
- 4 - WASHERS
- 4 - SPACER WASHERS
- 2 - NUTS

**REQUIRED TOOLS:**

- TORQUE WRENCH
- 22 MM WRENCH
- 22 MM SOCKET

|

**Thank you for your purchase! Whether you bought this Rock Hard 4x4 product from one of our fantastic dealers or our factory direct team, we thank you for your business.**

Rock Hard 4x4 is a family owned and operated business. We are headquartered in Saint Paul, Nebraska where we design, fabricate, and produce every single one of our products. Every single part we manufacture is 100% Made in the USA and exclusively in house by the Rock Hard 4x4 team.

We outsource zero processes.

**To you**, that means the product you are installing is the highest quality and longest lasting component on the market.

**To us**, that means you've selected a part we've spent years developing. Each Rock Hard 4x4 part has gone through more research and development and evolution than most people realize. While our parts may have the same striking look year after year, subtle revisions and refinements we implement maintain their status as the most durable and easy to install on the market.

**FITMENT:** Not compatible with alignment cam or cam bolts.  
Not compatible with aftermarket vehicle axle housings.

1. Ensure vehicle is in park with parking break set, on level ground, tires blocked.
2. Remove lower (housing side) control arm bolts/nuts – do one control arm at a time to prevent axle housing from rotating. Hold control arm and joint in place in factory control arm mount.
3. Install skid plate over control arm mount and align holes.
4. Tighten nut and bolt, torque to 130 ft. lbs.
5. Repeat for other side.