



**ROCK HARD 4X4 JEEP WRANGLER TJ/  
LJ 1997P 2006 FLOOR MOUNTS  
PART #: RH-1001-D  
Installation Manual**



## **PACKING LIST:**

- 1 - TJ DRIVER SIDE FLOOR MOUNT**
- 1 - TJ PASSENGER SIDE FLOOR MOUNT**
- 2 - 1/2" BOLTS**
- 2 - 1/2" SPACERS**

## **REQUIRED TOOLS:**

- CRESCENT WRENCH**
- BLADE (OPTIONAL CARPET TRIMMING)**
- 1 5/16" SOCKET**
- 3/4" WRENCH**

**Thank you for your purchase! Whether you bought this Rock Hard 4x4 product from one of our fantastic dealers or our factory direct team, we thank you for your business.**

Rock Hard 4x4 is a family owned and operated business. We are headquartered in Saint Paul, Nebraska where we design, fabricate, and produce every single one of our products. Every single part we manufacture is 100% Made in the USA and exclusively in house by the Rock Hard 4x4 team.

We outsource zero processes.

**To you**, that means the product you are installing is the highest quality and longest lasting component on the market.

**To us**, that means you've selected a part we've spent years developing. Each Rock Hard 4x4 part has gone through more research and development and evolution than most people realize. While our parts may have the same striking look year after year, subtle revisions and refinements we implement maintain their status as the most durable and easy to install on the market.

*PLEASE NOTE: RH-1001 cage required.*

*PRO TIP: These instructions coincide with RH-1001 Sports Cage Instructions.*

1. Install cage through step 14 before installing Floor Mounts. You will not use 3/8' x 3/4" x 2" plates as nuts for the dash bolts. They are only put together so you know which tubing goes with what bar. Take them apart prior to install.
2. Begin with passenger side. Install 3/4" x 1 1/2" bar in first with the offset clearing the dome light switch. Start three bolts. Bring tubing piece up from under dash and bolt in place with the two 1/2" bolts and spacer.
3. Bend driver side computer hook up and out of way. There is a wiring harness support on some years that must be moved to get the 3/4" bar in. When floor mount is installed you can bend the computer hook back near original position. On manual transmission vehicles it helps to hold clutch pedal down to get the tube in place.