



**ROCK HARD 4X4 JEEP CJ, YJ, TJ/LJ**  
**1976P 2006 LEGENDARY FRONT WINCH BUMPER**  
**PART #: RHP 400X**  
**Installation Manual**



**PACKING LIST:**

**1 - FRONT BUMPER**

**REQUIRED TOOLS:**

**TORX T55**

**Thank you for your purchase! Whether you bought this Rock Hard 4x4 product from one of our fantastic dealers or our factory direct team, we thank you for your business.**

Rock Hard 4x4 is a family owned and operated business. We are headquartered in Saint Paul, Nebraska where we design, fabricate, and produce every single one of our products. Every single part we manufacture is 100% Made in the USA and exclusively in house by the Rock Hard 4x4 team.

We outsource zero processes.

**To you**, that means the product you are installing is the highest quality and longest lasting component on the market.

**To us**, that means you've selected a part we've spent years developing. Each Rock Hard 4x4 part has gone through more research and development and evolution than most people realize. While our parts may have the same striking look year after year, subtle revisions and refinements we implement maintain their status as the most durable and easy to install on the market.

## **REMOVING FACTORY FRONT BUMPER**

1. Remove front bumper mounting hardware with T55 Torx head socket and wrench. If plastic valence is installed, remove and discard.
2. Unclip factory fog lights (if equipped).
3. Remove front bumper from vehicle.

## **INSTALLING WINCH (CAN BE DONE WITH FRONT BUMPER INSTALLED ALREADY)**

1. Set winch onto front bumper and install using supplied hardware in winch mounting kit. Usually 4 bolts.
2. Install fairlead onto front bumper using supplied hardware in winch mounting kit.

## **INSTALLING FRONT BUMPER**

1. Set bumper onto frame, line up holes, ensure distance from fenders is same side to side, and tighten factory hardware using T55 Torx head socket and wrench.