

## **Installation Instructions for Ford AXOD-E MCCC Solenoids**

1. Unplug transmission wiring harness from old solenoid.
2. Remove old solenoid.
3. Insert new solenoid assembly into valve body.
4. Slide mounting bracket over locating post on solenoid.
5. Plug in original wire harness.

**NOTE:** Be aware that solenoid may rotate during normal operation. Position lead wires away from any moving parts.

6. Make sure solenoid and bracket are correctly positioned before tightening mounting bolts.

**NOTE:** This is a P.W.M. lock-up type solenoid. Do NOT substitute this unit for an On/Off type solenoid. Permanent transmission or ECM damage may occur.

