



# A4BF3 Solenoid Kit Installation Instructions

1. Remove Original solenoids and old wire harness retaining clips.
2. Install Rostra solenoids in the positions as indicated in the diagrams below.
3. Route wiring as shown in the diagrams. Re-attach the original wire harness retaining clips to the Rostra wiring harness, and re-attach to the valve body.
4. Secure the solenoid Ground connections under the mounting bolts as shown. Ground connections may be doubled as shown.

