



Subaru Adapter Kit Instructions

PROCEDURE:

1. Install o-rings as illustrated in Figure 1. Be sure to place the thin o-ring on the top (brass side) of the solenoid to act as a spacer.
2. Assemble the kit by placing the solenoid on top of the port and placing the can over the solenoid as shown in Figure 2. There should be a small gap between the port and the can.
3. Insert the black connector into the connector of the solenoid. Insert the Subaru harness into the black connector to complete the electrical connection.
4. Install in valve body.



Figure 1



Figure 2