



CAMARO COLD AIR INTAKE SYSTEM With Magnuson S/C

For Magnuson S/C applications, the instructions are the same with the following exceptions:

Part #6 is a 4"x4 1/4" ID transition hump hose

Part #9 is a 3/8"x1/4" NPT *straight* fitting

Part #16 is 21 1/2" long instead of 12 1/4"

The 4" (small) side of the #6 transition hump hose locates on the throttle body. The #9 fitting mounts to the 1/4" NPT fitting in the inlet elbow. After installing the inlet elbow, route the breather hose straight back, then under the throttle body and to the right valve cover fitting. **MAKE SURE THE HOSE IS CLEAR OF ALL MOVING PARTS.**