



Wheel Spacer Set

Part #: RT32015 & RT32016

Kit Components:

- (2) Wheel Spacers
- (10) Wheel Bolts
- (10) Lug Nuts
- Thread Locker



-Read all instructions carefully prior to starting installation.

1. Ensure that all components in kit are accounted for.
2. Park on a flat, level surface.
3. Set the parking brake and chock a wheel not being raised. Loosen the lug bolts.
4. Safely raise the vehicle and set on a jack stand.
5. Remove the lug bolts. Remove the wheel. The factory lug bolts are no longer needed.
6. Clean the wheel mounting surface of both the hub and the wheel. Remove the rotor/drum retainer clips if present.
7. Install a Wheel Spacer using the included Wheel Bolts, adding a few drops of Thread Locker onto each Wheel Bolt prior to installation. Do not add any Thread Locker to the wheel studs that are pressed into the wheel spacers. Ensure the wheel spacer is sitting flush on the wheel mounting surface. Torque the wheel bolts in a star pattern to 95 ft. lbs.
8. Install the wheel to the Wheel Spacer using the supplied Lug Nuts. Ensure the wheel is sitting flush on the wheel spacer. Torque the Lug Nuts in a star pattern to 95 ft. lbs.
9. Lower the vehicle.
10. Repeat Steps 3-9 on the other side.
11. Re-torque all hardware after 50 miles.



Replacement Parts

6502738 Lug Nut

While every attempt is made to ensure that the information contained in these instructions is correct, no liability can be accepted by the authors for loss, damage, or injury caused by any errors in, or omissions from the information given. All service should be performed by qualified mechanics. Crown Automotive Sales Co., Inc. cannot be held responsible for any mechanical work performed. Standard and accepted safety precautions should be used in every procedure

Discover other steering wheels on our website.