

RUGGED OFF ROAD

6-100, 6-101

2004-15 Nissan
Titan/Armada

Step by step instructions and checklist: Use the proper tools and safety equipment to perform all work. Torque all fasteners to proper specifications and double check work. Align your vehicle after installation.



<p>Raise and support front of vehicle</p>	<p>Remove front wheels/tires</p>	<p>On backside of spindle remove ABS/brake line bracket</p>
<p>Disconnect dr/pass sway bar end link from bar, move down</p>	<p>Remove (3) upper strut mounting nuts</p>	<p>Remove lower strut mounting bolt/nut</p>
		<p>Re-assemble by reversing the steps above taking care to tighten each fastener. Repeat these steps on the opposite side of the vehicle. Reattach ABS/brake line brackets and tighten upper/lower coil-over mount hardware to factory specs</p>
<p>Push suspension down and remove strut from vehicle.</p>	<p>Mount new spacer to top of strut with hardware provided. Re-install strut rotated 180 degrees for proper hardware alignment.</p>	
<p>When completed reattach the sway bar end links on both sides of the vehicle simultaneously. Reinstall wheels/tires on vehicle, lower to the ground and torque to factory specs. Have truck aligned.</p>		