



Front Rock Crawler Tube Bumper NO DRILLING REQUIRED
P/N: 11502.11 and 11502.12

IMPORTANT NOTICE:

Carefully read instructions before attempting to install this product. Omix-Ada nor Rugged Ridge is in no way responsible for any damage to the vehicle or personal injury that may occur during the installation or use of this product.

CAUTION: This product is designed primarily to enhance the appearance of the vehicle. DO NOT rely in any way on the Guard to protect against injury or death in the event of an accident. “WEAR SEAT BELTS AT ALL TIMES”

INCLUDED COMPONENTS



<u>DESCRIPTION</u>	<u>QTY</u>
Front Bumper	1
Installation Instructions	1





INSTALLATION INSTRUCTIONS

1. Remove factory front bumper and save the existing factory hardware.
2. Install Rock Crusher Front Bumper onto vehicle using the factory hardware removed in step one.

Please take care when assembling and installing this product to protect the finish and your investment.

To protect your investment, wax this product after installing. Regular waxing is recommended. Do not use any type of polish/wax that contains abrasive that could damage the finish.

This front Rock Crawler grill guard is a genuine Rugged Ridge precision built bumper that mounts to the frame for the off road look and added protection. It has been designed and engineered to give long lasting service to your vehicle. Thank you for choosing a **Rugged Ridge** product.

