



Installation Instructions
Front Tubular Bumper For
1976-2006 CJ7 and Wranglers

Parts List: (1) Front Tube Bumper
DO NOT DISCARD ORIGINAL HARDWARE

Important Notice: To obtain the correct installation, We recommend that you follow these instructions carefully. Please review the instructions before proceeding to install front bumper. Please take care when installing this product to protect the finish and your investment.

Installation Instructions

Step (1) Remove the front bumper from the vehicle. **DO NOT DISCARD ORIGINAL HARDWARE.** It will be reused for the new bumper installation.



Step (2) Position the new front bumper up to the frame and line up holes to factory mounting locations. Using the stock bolts and supplied flat washers secure bumper to vehicle. Be sure to use all hardware supplied and tighten all bolts.

