

GENERAL INSTALLATION INSTRUCTIONS FOR TAPE MOUNTED ACCESSORIES

1. Clean mounting surface with isopropyl alcohol (rubbing alcohol). Avoid areas that the item will not be adhered to. Allow surface to dry completely before attaching item. Also, be sure the surface temperature is between 18-43°C (65-110°F) prior to application.

THIS MUST BE DONE FOR ADHESIVE TAPE TO PROPERLY STICK. FAILURE TO CLEAN COULD RESULT IN POOR ATTACHMENT AND FAILURE OF ITEM TO STAY ATTACHED.

2. Test fit item to the vehicle before removing the plastic liner from the double-sided tape. This will aid in aligning the piece properly before securing to the vehicle.

3. Remove liner from the double-sided tape. The liner can be removed easier with the aid of a knife or cutting blade. Peel from leading edges and pull away from tape as shown in Figure 1.



Figure 1

4. Carefully align item to its proper location on the vehicle and press firmly to ensure proper contact. Be sure item is securely attached before operating the vehicle. Maximum adhesion occurs within 24 hours of application.