

## Rugged Ridge Floor Liners

**Contents:**

Floor Liners (Qty. Varies)  
Logo (1 per Floor Liner)  
Logo Clips (2 per Floor Liner)

1. Confirm position and orientation of each Floor Liner, marked on the back of each part, in the vehicle.
2. Position the Logo over the oval recess in the Floor Liner and press it into place, ensuring that the two tabs push through the holes in the Floor Liner. Flip the Floor Liner over. Position the Logo Clips over the tabs and push them into place. To ensure that the logo is held tight, use a small socket to push the clips on more tightly.



3. Install Floor Liners into vehicle. For vehicles equipped with factory floor mat hooks, the Floor Liner is designed to work with them. Simply push the Liner over the hook until it goes all the way through the liner and locks in position. Please note that some years of a vehicle came with a hook while other years did not. For this reason some floor liner application require that you cut the molded attachment location for use with the factory floor hook. The liner has pre-marked locations on the bottom side of the recessed floor hook location. Carefully cut at the marked locations with a utility knife. If you vehicle does not have factory floor hooks then no modification is necessary.

