

(4) PC Light Guard Kit for TJ (Black)

P/N: 5670

Step (1) Remove the front turn signal mounting screws.
Place front guard over lamp and attach with longer supplied screws. Repeat for other side.

Step (2) To mount the side marker lamps place one guard over the lamp and mark the mounting hole location with a scribe or pen. Use a 3/16" drill bit and drill drill holes in the flare at the scribed spots. Use the supplied allen head bolts and nuts to secure the guard to the flare.

Note: Some Jeep models will require the use of the black spacers to clear bulges in the flare in relation to the side marker lamps. Not all of the spacers may be needed.

