

2007-08 Wrangler
Side Marker Light Euro-Guard
11231.11 - Black Powdercoated
11142.11 - Stainless Steel



Step 1. Begin by removing the bulb and socket assembly from the marker light. Twist the socket up and away from the vehicle until it loosens.



Step 2. With the bulb removed, locate the two housing retaining tabs (circled) and pry them outwards, releasing the housing.



Step 3. The housing may now be removed from the front of the vehicle.

Step 4. Align the 3 metal tabs with the 3 housing tabs (they are spaced uniquely and only go on one way). Slide the bottom guard tab over the housing until it clears the lens (use the lens stamping letters to determine bottom).



Step 5. Slide the remaining guard tabs onto the housing. The fit will be tight.



Step 6. With the guard seated onto the housing, squeeze the guard tabs tightly for a snug fit.



Step 7. Re-insert the housing into the grille. Push the housing back until it snaps into place.



Step 8. Reinstall the bulb/socket assembly, remembering to rotate it to secure it to the housing.



Step 9. Installation is now complete!