

CHROME TRIM INSTALLATION



NOTE:

- **Handle with care!**
 - Protect your **Chrome Trim Pieces** from impact and excessive bending which will damage their appearance.
-

What you will need:

- Clean work area, free of airborne dust, and debris
 - Vehicle and **Chrome Trim piece**
 - Temperatures above 65°F
 - 3M Adhesive Cleaner (PN08984) or equivalent (optional)
 - **Soft Clean Cloth**
-

Pre-Installation:

- **DO NOT remove the red tape liner until instructed to do so.**
 - **Test Fit Each Piece:** Lay out and test fit the **Chrome Trim Pieces** before starting. Check that the shape and form of each piece properly conform to the surface area. Each piece is designed to fit the contour of the vehicle on every location it is intended to be installed.
 - Note the proper placement and alignment.
 - Clean the receiving surface just prior to installation. Use 3M adhesive cleaner, or its equivalent, to clean the area thoroughly. **The receiving surface must be dry and clean.**
 - Apply 3M adhesive Promoter: If applying on a plastic surface, an adhesive promoter (preferably 3M) should be applied.
-

Installation:

- Remove the entire red liner. **Protect the exposed tape from contaminants and debris.**
 - Hold the piece at a 90° angle to the application surface, making contact with the very top edge. Observe your placement and alignment guides. Adjust accordingly before the adhesive tape makes contact.
 - Once you get the placement right, press down across the top of the piece to tack it into place. Complete the installation by pressing down across the piece with a soft clean cloth, moving top to bottom.
 - Lastly, apply pressure over the entire surface including the edges to ensure that the tape completely adheres to the surface. Check your edges and reapply pressure where necessary.
 - You may use any non-abrasive stainless steel cleaner to keep your **Chrome Trim Accessories** shining bright!
 - DO NOT wash vehicle for 24 hours after installation
-

IMPORTANT!

- **Once the tape adheres to the vehicle, the **Chrome Trim** cannot be taken off without being damaged. The surface of the vehicle, however, will not sustain any damage if the **Chrome pieces** are removed in the future.**