

# Auto Installation Instructions IMPORTANT - Follow All Directions Carefully When Installing AUTO-TRAC



surface, remove all tangles and ensure the side wire hooks are facing down

Do not drive with chains that are damaged · Slide the inside side cable (A) and chain behind th wheel. Find the split (B) in the front side chain. Lay one half of the chain in front of the tire and the other



in front of the outer side wall. . Connect the side cable together by inserting the kno into the key-hole latch (C) . Leave the connected side

CAUTION: You could damage your side walls if the side wire hooks are not facing

cable draped over the outer sidewall (D) while you



and flip the red lever up to install. Pull the red cable end out and attach to the

green side chain connecter (F)



up position and slide the side cable to the back of the tire (G), ensure the chain is centered on the tire.



(H) and flip the red lever up install. Pull the red cable end out and connect to the side chain connector (I). PINCH WARNING: Keep your fingers clear of the chain and tensioner while engaging



tighten both the top and bottom tensioners. Your chains will begin to self tighten

### LIMITED WARRANTY

(A) A) DISCLAIMER O ARRANTIES: Peerless warrants free from defects in workmanship and materials for 90 days from purchase date of this product to owner. Warranty does not include damage due to product failure, misuse, abuse or cost of inconvenience. No other express warranty is given and no affirmation, by words or action, shall constitute a warranty

The buyer's sole remedy for breach of any warranty is limited exclusively to obtaining, at the discretion of the seller, either credit or repair or replacement of any product sold hereunder and manufactured by Peerless Chain Company within 90 days after deliver to the owner.

Although this warranty gives you specific rights, you may have other legal rights which differ from state

SPEEDS OVER 30 MPH\_IMPROPER INSTAL-LATION OR IMPROPER FIT VOIDS WARRANTY.



## **IMPORTANT INFORMATION:**



### AUTO-TRAC Chain Removal Instructions

1. Park your vehicle with the green side-chain connector (F) at the 1:00 o'clock position. This will ensure easy removal of the tire chains without re-positioning your vehicle. CAUTION: Park your vehicle off-road with the engine off and the emergency brake set before removing your AUTO-TRAC™ chains.

Z. Grasp the bottom tensioner (H) and flip the red lever up to remove. Pull the red cable out of the side-chain connector (I). Firmly grasp the red cable end and flip the red lever down to take up the exposed cable. PINCH WARNING: Keep your fingers clear of the cable while allowing the cable to re-seat into the tensioner.

3. Grasp the top tensioner (E) and flip the red lever up to remove. Pull the red cable end out of the side-chain connector (F). Firmly grasp the red cable end and flip the red lever down to take up the exposed cable PINCH WARNING: Keep your fingers clear of the cable while allowing the cable to re-seat into the tensioner

4. Bring the back side cable forward and disconnect (Refer to step 2 photo).

