



1994 - 2011 DODGE 1500 - 3500
4WD

PITMAN ARM
PART # DA300, DA302, DA303,
DA309, DA600, & DA602

1. Remove the drag link from the pitman arm & lower it down. (See Photo # 1)
2. Remove the pitman arm from the steering sector. **Note:** A pitman arm puller will be required. (See Photo # 2). Install the new Skyjacker® drop pitman arm using the OEM hardware & torque to the OEM specs. Completely remove the OEM stabilizer. **Note:** The OEM stabilizer cannot be reinstalled when using a drop pitman arm, but a replacement one is available from skyjacker®. Refer to a Skyjacker catalog for make & model part #'s.
3. Loosen the turn buckle clamps on the drag link, rotate 180°, & install in the bottom end of the new pitman arm. (See Photo # 3) Tighten to the OEM specs (be sure to install cotter key). Tighten the turn buckle with the clamps & bolts rotated to the top side of drag link to provide clearance for the steering stabilizer boot.

