



Jeep Wrangler JK OEM Replacement Steering Stabilizer Part # 7003

Contents:

Part #	Description	Qty
7202WS	WHITE STEERING DAMPER	1
142121	STEEL SLEEVE	2
HG58125	HOURGLASS BUSHING	2
B12RS	RED BOOT	1
BTIE	RED BOOT TIE	1
HSS	HYDRO SHOCK DECAL	1

Installation:

1. Park the vehicle on flat level ground & set the emergency brake.
2. Turn the tires / wheels to a straight forward position.
3. Remove the OEM steering stabilizer from the vehicle.
4. Install the supplied red boot over the new Skyjacker steering stabilizer.
5. Install one poly bushing & steel sleeve at each end of the steering stabilizer & install using the OEM hardware.

Note: Be sure to install so the cylinder body is mounted to the axle side as shown in the photo below. If mounted the opposite way, damage can occur to the steering stabilizer.

6. After installation be sure to cycle the steering & check for adequate clearance. In most cases the OEM steering stabilizer bracket on the tie rod assembly will need to be rolled down slightly to allow for adequate clearance. After adjusting, check again for adequate clearance.
7. Re-tighten all bolts after the first 100 miles & periodically thereafter.

Seat Belts Save Lives, Please Wear Your Seat Belt.

