



**1970 - 1979 Ford
F-150 / Bronco
OEM Replacement Steering
Stabilizer
Part # 7030**

Contents:

Part #	Description	Qty
7800	WHITE STEERING DAMPER	1
142120	STAB WASH PKG	2
STEM BUSH-SST	STEM BUSHING-STEERING STAB.	4
B10RS	RED BOOT	1
BTIE	RED BOOT TIE	1
HSS	HYDRO SHOCK DECAL	1
I-7030	INST. SHEET FOR 7030	1

Installation:

1. Park the vehicle on flat level ground & set the emergency brake.
2. Turn the tires / wheels to a straight forward position.
3. Remove the OEM steering stabilizer from the vehicle.
4. Install a washer & poly bushing on each end of new Skyjacker steering stabilizer & install on the vehicle.
5. Install a poly bushing & washer on each end of new Skyjacker steering stabilizer.
6. Tighten until the bushings start to squeeze out around the washer.
7. Re-tighten all bolts after the first 100 miles & periodically thereafter.

Seat Belts Save Lives, Please Wear Your Seat Belt.

