



**1967 - 1987 GM 4x4
OEM Replacement Steering
Stabilizer
Part # 7055**

Contents:

Part #	Description	Qty
7000	WHITE STEERING DAMPER	1
HOURLASS 5/8	HOURLASS 5/8 SHOCK BUSHING	2
140629	EB6 STUD BAG - P932/140629	1
P837	STAB TAPERED STUD/141264	1
B10RS	RED BOOT	1
BTIE	RED BOOT TIE	1
HSS	HYDRO SHOCK DECAL	1

Installation:

1. Park the vehicle on flat level ground & set the emergency brake.
2. Remove the OEM steering stabilizer.
3. Install the tapered stud into the tie rod & tighten.
4. Install the bushing & sleeve onto the body end of the new Skyjacker steering stabilizer & place onto the OEM axle bracket & tighten.
5. Install the boot over the shaft of the new steering stabilizer & install the bushing. Mount the shaft end of the new steering stabilizer to the the stud on the tie rod & tighten.
6. After installation of the steering stabilizer, cycle steering left to tight & check all components for adequate clearance.
7. Re-tighten all hardware after the first 100 miles & periodically there after.

Seat Belts Save Lives, Please Wear Your Seat Belt.

