



2001- 2003 GM 2500 HD 4WD
2002- 2003 GM Hummer H2 4WD
OEM Replacement Steering
Stabilizer
Part # 7098

Contents:

Part #	Description	Qty
7202WS	WHITE STEERING DAMPER	1
HOURGLASS 5/8	HOURGLASS 5/8 SHOCK BUSHING	1
HG58125	HOURGLASS 5/8,1.25" LONG	1
P837	STAB TAPERED STUD/141264	1
403712	ES22 SLEEVE/1.25" LONG	1
B12RS	RED BOOT, SMALL	1
BTIE	RED BOOT TIE	1
HSS	HYDRO SHOCK DECAL	1
I-7098	INST SHEET FOR 7098	1

Installation:

1. Park the vehicle on flat level ground & set the emergency brake.
2. Set the tires / wheels in a straight forward position.
3. Remove the OEM steering stabilizer from the frame & from the center steering link.
4. Install the 1 1/4" long bushing into the "body" end of the new Skyjacker steering stabilizer & install the 1 1/4" long sleeve into the bushing. (See Photo # 1)
5. Install the 5/8" hourglass bushing, which is 1 1/2" long, into the shaft end of the new steering stabilizer. (See Photo # 2)
6. Install the tapered stud into the center steering link using the supplied nut & washer & tighten in place. Slide the shaft end of the steering stabilizer over the stud & tighten in place using the supplied nut & washer. (See Photo # 2)
7. Attach the body end of the steering stabilizer to the OEM mount on the frame using the OEM hardware.
8. After installation of the steering stabilizer, cycle steering left to tight & check all components for adequate clearance. Re-tighten all hardware after the first 100 miles & periodically there after.



Photo # 1



Photo # 2

Seat Belts Save Lives, Please Wear Your Seat Belt.