



GM, Dodge, Ford, Jeep, Scout Single Steering Stabilizer Part # 7110

Part #	Description	Qty.
7800	WHITE STEERING DAMPER	1
83170	MAIN BRKT FOR 7110	1
83161	UNIVERSAL TIE ROD BRACKET	1
38X318X312U	3/8 X 3 1/8 X 3 1/2 RD/UBLT	2
516X114X134U	5/16 X 1 1/4 X 1 3/4 U-BT R	2
38CTN	3/8-16 COARSE N/I LOCK NUT	4
38SAEW	3/8 SAE WASHER	4

Part #	Description	Qty.
516CTN	516-18 COARSE N/I LOCK NUT	4
516SAEW	5/16 SAE WASHER	4
STEM BUSH-SST	STEM BUSHING-STEERING STAB.	4
142120	STAB WASH PKG - P889/145098	2
B10RS	RED BOOT	1
BTIE	RED BOOT TIE	1
HSS	HYDRO SHOCK DECAL	1

Note: Skyjacker steering stabilizer Part# 7110 is designed to fit several makes of vehicles covering several years. Configuration of the front end of your vehicle will determine where you mount the stabilizer. Differential cases are located either on left or right side depending on vehicle. This stabilizer can be installed on either side.

Installation:

1. Park the vehicle on flat level ground & set the emergency brake.
2. Place the tires / wheels to a straight forward position.
3. Install bracket "A" to the axle housing tube per the illustration using the supplied u-bolts & nuts. Do not tighten at this time. Install the stabilizer onto bracket "A" using the supplied bushings & washer packs.
4. Install the shaft end of the stabilizer to bracket "B".
5. Extend the stabilizer shaft out 4.44" (exactly half way) & mount to the tie rod using the supplied u-bolts & nuts. Rotate the tie rod bracket as needed to obtain the best position. Tighten all hardware securely at this time.
6. Cycle the tires / wheels left to right & check all hardware for clearance. Re-tighten after the first 100 miles & periodically there after.

