



1961-1982 Toyota Landcruiser Single Steering Stabilizer Part # 7160

Part #	Description	Qty.
7900	WHITE STEERING DAMPER	1
83167	MAIN BRACKET FOR 7160	1
83161	UNIVERSAL TIE ROD BRACKET	1
38X312X412U	3/8 X 3 1/2 X 4 1/2 U-BL R	2
516X114X134U	5/16 X 1 1/4 X 1 3/4 U-BT R	2
38CTN	3/8-16 COARSE N/I LOCK NUT	4
38SAEW	3/8 SAE WASHER	4

Part #	Description	Qty.
516SAEW	5/16 SAE WASHER	4
516CTN	516-18 COARSE N/I LOCK NUT	4
STEM BUSH-SST	STEM BUSHING-STEERING STAB.	4
142120	STAB WASH PKG - P889/145098	2
B10RS	RED BOOT	1
BTIE	RED BOOT TIE	1
HSS	HYDRO SHOCK DECAL	1

Note: Skyjacker steering stabilizer Part # 7160 is designed to fit several makes of vehicles covering several years. Configuration of the front end of your vehicle will determine where you mount the stabilizer. Differential cases are located either on left or right side depending on the vehicle. This stabilizer can be installed on either side.

Installation:

1. Park the vehicle on level ground & place the tires / wheels in a straight forward position. Set the emergency brake & block the rear tires.
2. Install bracket "A" onto the axle housing tube per the illustration. Install using the u-bolts & nuts. Do not tighten at this time. Install the stabilizer onto bracket "A" using the bushings & washer packs provided.
3. Install the shaft end of the stabilizer to bracket "B".
4. Extend the stabilizer shaft out 4"(exactly half way) & mount onto the tie rod using the u-bolts & nuts. Rotate the tie rod bracket as needed to obtain the best position. Tighten all hardware securely on bolts & u-bolts at this time.
5. Cycle the tires / wheels left to right & check all hardware for clearance. Re-tighten after the first 100 miles & periodically there after.

