



1979-1985 Toyota Pick Up Single Steering Stabilizer Part # 7070 / 7175

Part #	Description	Qty.
7900	WHITE STEERING DAMPER	1
83161	UNIVERSAL TIE ROD BRACKET	1
516X1X134U	5/16 X 1 X 1 3/4 U-BOLT RD	1
38X112FTB	3/8 X 1 1/2 FINE THRD BOLT	1
516CTN	516-18 COARSE N/I LOCK NUT	2
516SAEW	5/16 SAE WASHER	2
38FTN	3/8-24 FINE N/I LOCK NUT	1

Part #	Description	Qty.
38SAEW	3/8 SAE WASHER	1
STEM BUSH-SST	STEM BUSHING-STEERING STAB.	4
142120	STAB WASH PKG - P889/145098	2
B10RS	RED BOOT	1
BTIE	RED BOOT TIE	1
HSS	HYDRO SHOCK DECAL	1

Installation:

1. Park the vehicle on flat level ground & set the emergency brake.
2. Place the tires / wheels to a straight forward position.
3. Install the cylinder, large diameter end, onto bracket "A" per illustration.
4. Extend the steering stabilizer shaft out 4" (exactly half way) & attach bracket "B" to the tie rod using the supplied u-bolt & 3/8" bolt. The 3/8" bolt will be attached to the lower forward hole on bracket "B". The u-bolt will be attached around the tie rod & through bracket "B".
5. Cycle the tires / wheels left to right & check all hardware for clearance.
6. Re-tighten all hardware after the first 100 miles & periodically there after.

Seat Belts Save Lives, Please Wear Your Seat Belt.

