



01-10 GM 2500 HD 4WD Dual Steering Stabilizer Part # 7298

PARTS LIST		
ITEM#	DESCRIPTION	QTY
7500WS	WHITE STEERING DAMPER	2
HB-7298	HARDWARE BAG FOR 7298	1
B12RS	RED BOOT, SMALL/FOR 7500WS	2
BTIE	RED BOOT TIE	2
HSS	HYDRO SHOCK DECAL	2
58USSW	5/8" LARGE USS WASHER	2
I-7298	INST. SHEET FOR 7298	1

HARDWARE BAG LISTING		
ITEM#	DESCRIPTION	QTY
7298-MB	GM 3/4T,7298 MAIN STAB BRKT	1
7298-DT	GM 3/4T,7298 DRIVER TAB BRK	1
7298-PT	GM 3/4T,7298 PASS. TAB BRKT	1
140629	EB6 STUD BAG - P932/140629	2
142120	STAB WASH PKG - P889/145098	2
HOURGLASS 5/8	HOURGLASS 5/8 SHOCK BUSHING	2
STEM BUSH-SST	STEM BUSHING-STEERING STAB.	4
516X114X134U	5/16 X 1 1/4 X 1 3/4 U-BT R	2
516CTN	516-18 COARSE N/I LOCK NUT	4
516SAEW	5/16 SAE WASHER	4

Installation:

1. Park the vehicle on flat level ground & set the emergency brake.
2. Place the tires / wheels to a straight forward position.
3. While supporting the front cross member with a floor jack, remove the front lower A-arm bolt at the frame using a 15/16" socket. **Note:** If installing on a vehicle with 3" or more lift, it will be the upper front bolt on the after market cross member.
4. Once the bolt is removed, re-install with the new Skyjacker outer stabilizer bracket. Place the large 5/8" washer between the bracket & the frame. (See Arrow in Photo #1) **Note:** Be sure to install the bolt pointing toward the rear. Mount the new bracket so the tab sticks back & outward toward the tire / wheel. Attach the steering stabilizer stud to the bracket. (See Photo # 2) Repeat this process on the passenger side.
5. Mount the new Skyjacker center main bracket to the center link using the supplied u-bolts, washers, & nuts. Do not tighten the u-bolts at this time. (See Photo # 3)
6. Attach the cylinders to the main bracket & outer bracket. (See Photo # 4) Center the main bracket so that both cylinders are pulled out equal distances. (See Photo # 4 & # 5)
7. Cycle the steering left to right & check all parts for adequate clearance.
8. Retighten all hardware after the first 100 miles.

Note: This steering stabilizer kit is designed for the 01-10 GM 2500 HD 4WD with 3"-6" lift heights. This kit will **NOT** work on vehicles with a lift kit that relocates the upper A-arms.

