

Installation Instructions for Ford Full Size Transit hinged door

Step 1- Remove left side door striker plate using T40 star socket. Place left side bracket PN# FD-T1- SIDE- LEFT over striker plate holes firmly hold bracket against door jam. Reinstall striker plate over bracket and tighten T40 Star bolts.

Step 2- Install right side door bracket by removing two T27 star bolts- holding door latch in place (leave third screw in place to retain latch position) Install bracket PN# FD-T1- SIDE- RIGHT using the two allen screws provided, leave screws loose enough to adjust right bracket to match left bracket.

Step 3- Once alignment of brackets is good. Tighten allen screws. Slowly close left and right doors to check for Proper alignment

Step 4 - Install spinner on lock and install lock on bracket

See back side for rear door instructions

Installation Instructions for Ford Full Size Transit Hinged Doors

STEP 1 Rear Doors

Remove two star bolts securing left rear door striker plate. Hold left rear bracket PN # FD-T1-REAR-LEFT over mounting holes and mark weather stripping top and bottom bracket points. Carefully cut away weather stripping retaining casing between top and bottom marks. Use sharp Razor knife to completely cut out metal spring material along retaining casing seam. **Do not cut away weather strip door gasket it will remain in place.** Install Slick Lock (FD-T1-LEFT REAR)bracket over striker plate and reinstall with flange bolts provided. Make sure weather stripping is secured and tight on door edge.

STEP 2 Rear Doors

Remove two star bolts on right rear door lock latch mechanism, leave third bolt in to hold latch in place. Place Slick Locks bracket PN# FD-T1-REAR-RIGHT over mounting holes and install using two bolts provided. Only hand-tighten this side.

CAUTION – Slowly close left then right door making sure weather stripping clears left bracket. Once doors are closed, align lock holes with RD Pin – (dowel pin, drill bit, etc.) When you are satisfied with alignment, slowly open right side door and torque down both bolts. Shut rear door firmly.

If lock is difficult to slide on and off or difficult to close –Realign right side until desired fit is achieved – brackets can also be modified with round file or drilling center hole to accommodate various lock brands. Be careful to not damage your vehicles painted finish.

Installation Instructions for Ford Full Size Transit Hinged Doors

STEP 1 **Rear Doors**

Remove two star bolts securing left rear door striker plate. Hold left rear bracket PN # FD-T1-REAR-LEFT over mounting holes and mark weather stripping top and bottom bracket points. Carefully cut away weather stripping retaining casing between top and bottom marks. Use sharp Razor knife to completely cut out metal spring material along retaining casing seam. **Do not cut away weather strip door gasket it will remain in place.** Install Slick Lock (FD-T1-LEFT REAR)bracket over striker plate and reinstall with flange bolts provided. Make sure weather stripping is secured and tight on door edge.

STEP 2 **Rear Doors**

Remove two star bolts on right rear door lock latch mechanism, leave third bolt in to hold latch in place. Place Slick Locks bracket PN# FD-T1-REAR-RIGHT over mounting holes and install using two bolts provided. Only hand-tighten this side.

CAUTION – Slowly close left then right door making sure weather stripping clears left bracket. Once doors are closed, align lock holes with RD Pin – (dowel pin, drill bit, etc.) When you are satisfied with alignment, slowly open right side door and torque down both bolts. Shut rear door firmly.

If lock is difficult to slide on and off or difficult to close –Realign right side until desired fit is achieved – brackets can also be modified with round file or drilling center hole to accommodate various lock brands. Be careful to not damage your vehicles painted finish.