

## Installation Instructions for Nissan 200/GM CITY EXPRESS Sliding Doors

**Step 1- Slide door to FULL open position- locate lock striker plate at rear of van door jam. Slider bracket mounts at rear edge of sliding door.**

**Step 2- Remove two T-40 star bolts- holding on striker plate, place slider bracket over mounting bolts- use grease pencil to mark where bracket lays on outside of van side panel.**

**Step 3- Apply clear tape protector directly on van surface under round end of bracket to protect paint.**

**Step 4- Hold bracket in place and reinstall striker plate on bracket- tighten star bolts- slowly close door and check for proper clearances.**

**Step 5- Close door firmly and apply clear tape protector on sliding door edge to protect paint from lock.**

**Step 6- Install spinner on lock and install lock on bracket- sliding door cannot pop out or slide back with lock in place.**

### **STEP 1**

**Remove two bolts securing left rear door lock striker latch. Hold left rear bracket PN # NV200-ID-REAR LEFT over mounting holes and mark weather stripping top and bottom bracket points. Carefully cut away weather stripping retaining casing between top and bottom marks. Do not cut away weather strip door gasket it will remain in place. Install bracket ON TOP OF striker latch and reinstall bolts. Make sure weather stripping is secured on door edge.**

### **STEP 2**

**Remove two Phillips screws holding right rear door striker plate (use impact or hammer drill with proper bit) (be careful not to strip screw heads) Install bracket loosely and properly align with left side bracket. After proper alignment tighten Phillips screws, slowly close doors and adjust as needed. Brackets can be filed down to obtain a perfect match and center hole can be opened up with round file if required. Install puck locks on all doors (always use Slick Locks NPS-10 spinners and weather covers on all locks.**