

## 2007-09 Yukon/Tahoe/Avalanche/Suburban, Axle Back with Dual Tip

**PACKING LIST**

*Before installation, use this check list to make sure all necessary parts have been included.*

ITEM	QTY	CHECK	PART NUMBER	DESCRIPTION
1.	1	<input type="checkbox"/>	310301590	Assy, Pipe, Axle Back, Single, Yukon/Tahoe/Avalanche/Suburban, 900 Series
2.	1	<input type="checkbox"/>	310301853	TIP ASSY, TRUCK, DUAL OUTLET, REPLACEMENT TIP F31041/31668
3.	1	<input type="checkbox"/>	308144380	Clamps, Torca, 2.5"
4.	1	<input type="checkbox"/>	10271	Clamps, Torca, 2.75"
5.	1	<input type="checkbox"/>	*****	Instructions

**WARNING:** SLP Recommends allowing the vehicle to cool (not running) for five hours before beginning installation.

**INSTALLATION INSTRUCTIONS – #31059**

- 1 Begin the install by measuring 7 ¾" from the factory exhaust hanger and making a clear mark, then cutting off the factory resonator, see photo 1.



**Photo 1: Stock Resonator Removed from Vehicle**

- 2 Install the SLP hanger onto the factory rubber isolator and then slide the SLP pipe over the factory pipe. Install the tip onto the SLP pipe and then tighten all clamps after adjusting the system, see photo 2 below.



**Photo 2: SLP System Installed**

- 3 The installation is now complete! ENJOY!