

## PART # M31023

# 2011 Mustang GT, Axle-Back Exhaust

#### **PACKING LIST**

Before installation, use this checklist to make sure all necessary parts have been included.

ITEM	QTY	PART NUMBER	DESCRIPTION
1.	1	310803787	Tail Pipe, Rear DS, '11-'14
2.	1	310803788	Tail Pipe, Rear, PS, '11-'14
3.	2	310305080	Tip, 4" OD, 2.5" Inlet, Polished, Slash Cut
4.	2	308144380	Clamps, Torca, 2.5"

WARNING: SLP Recommends allowing the vehicle to cool (not running) for five hours before beginning installation



#### INSTALLATION INSTRUCTIONS – # M31023

- 1. Raise and fully support the vehicle (a vehicle lift is recommended). If you do not have access to a lift, you may raise the rear using a jack/jackstands or by using drive-up type ramps.
- 2. Loosen the 2 factory bell/band clamps near the rear axle and remove the factory exhaust system. You may remove the factory rubber isolators but will be reusing them. A few sprays of WD-40 on the isolators makes removal and installation easier.
- 3. Using a cut-off wheel, cut the weld holding the clamp to the stock muffler. Then remove the clamp, this will be reused during installation.
- 4. Take a piece of wood about an inch thick and place it between the factory over-axle pipe and the upper panhard bar on each side to allow for adequate clearance when installing the axleback.
- 5. Place the factory hangers back onto the axleback hangers. Repeat for other side.
- 6. Place the stock bell/band clamp over the ball flange on the system and raise into place. Insert the isolators onto the hangers on the vehicle. Repeat for ot



Figure 1: Installation of DS Muffler Assembly

7. Place a torca clamp onto the exhaust tip and slide onto muffler assembly / rear tailpipe. Snug clamp but to not fully tighten. Repeat for other side.



- 8. Adjust system from front to back to allow for adequate clearance all around and tighten all clamps.
- 9. Test drive vehicle and inspect for any leaks.
- 10. The finished installation should look like Figure 2.



### **Figure 2: Finished Installation**

11. The installation is now complete. Enjoy!