



**Installation Instructions**  
**Low Profile Roller Fairlead**  
**Part # 2810**

**Note:** Read instructions entirely before installing this product. Always use caution when drilling and wear eye protection.

Parts Included	Qty	Parts Included	Qty
Roller Fairlead	1	M12 nut	2
M12 x 40mm Hex Bolt	2	M12 Flat Washer	2

**Step 1:** Remove current fairlead from bumper. (If equipped)

**Step 2:** Hold new roller fairlead on bumper centering it over the winch rope slot. (Fig A)

**Step 3:** Once fairlead is centered mark the holes. (Fig B)

**Step 4:** Set the roller fairlead to the side and drill out the previously marked holes. (Fig C)



(Fig A)



(Fig B)



(Fig C)



(Fig D)

**Step 5:** Hold fairlead back on bumper and insert included hardware. (Fig D)

**Step 6:** Make sure fairlead is centered and straight and then secure hardware. Installation is now complete