



# Installation Instructions

## Nerf Step (Part # T0654FJ)

### 04-08 Toyota FJ Cruiser

**NOTE: Carefully read entire instructions thoroughly before attempting to install this part.**

Parts Included	Qty
8mm x 1" bolt	10
5/16" Flat Washer	10
8 mm Lock Washer	10

Tools Needed
13mm Wrench



**STEP 1:** Remove the bars from the box and locate the hardware.

**STEP 2:** Identify the Driver and Passenger; the short end goes towards the front of the vehicle.

**STEP 3:** Remove the plastic cap between the pinch-weld and the underside floor pan.

**STEP 4:** Line up the bracket holes and insert hardware. Do not tighten completely at this time.

**STEP 5:** After all bolts have been placed, tighten the front bolt first and then the rear. Then proceed to completely tighten the remaining bolts. Repeat same process for opposite side.

#### Product cleaning and maintenance instructions

**Stainless Steel Finish** – Aluminum polish may be used to polish small scratches and scuffs on the finish. Mild soap, window or glass cleaner may be used to clean the finish. **Dual state powder coat finish** – Mild soap, window or glass cleaner may be used to clean the finish. In order to protect the finish, you may wax your product on a regular basis with pure carnauba automotive wax. Do not use any types of soap, polish or was that contains abrasive that could damage the finis