



Installation Instructions

Windshield Channel (Part # 90101)
1987-1995 Jeep Wranglers

NOTE: Carefully read entire instructions thoroughly before attempting to assemble and/or install this product.

Parts Included	Qty
Left Channel (Driver) side	1
Right Channel (Pass) side	1
#8 x 1/2" Phillips Pan Screw	11

Tools Needed
Phillips Screwdriver
Drill
1/8" Drill Bit

Section One

1. Place both channel pieces on top of windshield frame and center them. (Make sure the opening of the channel is facing forward.)
2. Mark holes using the channel as a template. **Note:** If a channel was previously installed you may not need to mark all of the holes. Now remove the channel.
3. Drill holes previously marked with a 1/8" drill bit.(Always use caution while drilling)
4. Place channel back on top of frame and secure with included sheet metal screws. Installation is now complete.