

### Instructions

# Chrysler 46RE, 46RH, 47RE, 47RH, 48RE, A727

#### 1. Disassembly

- a. Remove pan and valve body to expose bottom of the transmission.
  - b. Remove adjusting screw from the band.
  - c. Remove OE strut.

#### 2. Installation & Assembly

- a. Insert Sonnax strut with the flat surface facing away from the band.
- b. Replace OE adjusting screw and set to manufacturer's standards.

## Kickdown Band Strut

Part No. 22825-01