

SPEC-D *Tuning*

2004-2011 CHEVY COLORADO GMC CANYON PROJECTOR HEADLIGHTS INSTALLATION INSTRUCTIONS

*If you experience any difficulties that the instructions did not cover, Please seek assistance at local automotive shop.

*Please wear protection before you work on your vehicle.

*An assistant is useful when removing the front bumper from your vehicle.

*Please be cautious when working with the bumper or any parts belonging to the vehicles' body prevent scratching.

*Do not make direct contact with the halogen bulb or the wire assembly until the unit has cooled down after use.



TOOLS AND SUPPLIES REQUIRED

¼" Drive Ratchet

10mm Socket

Flathead Screwdriver

If your Headlight is Halo type, you also need:

Wire Stripper

Wire Crimper

4 Blue Quick Splice Wire Connectors

4 Blue Male Quick Wire Connectors

4 Blue Female Quick Wire Connectors

2 Red Wires (8 inch)

2 Black Wires (8 inch)

Product Part Numbers:

2LCLHP-COL04HJM-TM

2LCLHP-COL04H-TM



INSTALLATION INSTRUCTIONS

- *If you experience any difficulties that the instructions did not cover, Please seek assistance at local automotive shop.
- *Please wear protection before you work on your vehicle.
- *An assistant is useful when removing the front bumper from your vehicle.
- *Please be cautious when working with the bumper or any parts belonging to the vehicles' body prevent scratching.
- *Do not make direct contact with the halogen bulb or the wire assembly until the unit has cooled down after use.



1. Open the front hood



2. Release the retaining clip



3.. Release the bumper light retaining clip



4. Disconnect the bumper light harness



11. Place the projector headlight in the stock location



12. Tighten the (2) 10mm bolts



13. Replace the front grill



14. Connect the bumper light harness to the bumper light



15. Replace the bumper light. Please repeat the steps in order from 1 to 15 for the opposite side



16. The installation is now complete