

SPEC-D *Tuning*

2008 AND UP HONDA ACCORD 4DR PROJECTOR HEADLIGHTS INSTALLATION INSTRUCTIONS

If you experience any difficulties that the instruction did not cover, Please seek assistance at a local automotive shop

Please wear protection before you work on any vehicle.



An assistant is useful when removing the front bumper from your vehicle.

Please be cautious when working with the bumper or any parts belonging to the vehicle's body to prevent scratching.

Do not make direct contact with the halogen bulbs or the wire assembly until the unit has cooled down after use.

TOOLS AND SUPPLIES REQUIRED

1/4" Drive Ratchet

Trim Pad Remover

6" Extension

10mm Socket

Phillips Screwdriver

If your Headlight is Halo type, you also need:

Wire Stripper

Wire Crimper

4 Blue Quick Splice Wire Connectors

Blue Male Quick Wire Connectors

4 Blue Female Quick Wire Connectors

2 Red Wires (8 inch)

2 Black Wires (8 inch)

Product Part Numbers:

2LHP-ACD084JM-TM

2LHP-ACD084G-TM

2LHP-ACD084-TM



2008 AND UP HONDA ACCORD 4DR PROJECTOR HEADLIGHTS INSTALLATION INSTRUCTIONS

If you experience any difficulties that the instruction did not cover, Please seek assistance at a local automotive shop

Please wear protection before you work on any vehicle.



An assistant is useful when removing the front bumper from your vehicle.

Please be cautious when working with the bumper or any parts belonging to the vehicle's body to prevent scratching.

Do not make direct contact with the halogen bulbs or the wire assembly until the unit has cooled down after use.



1. (10) Plastic clip locations



2. Remove the (10) plastic clips



3. Remove the phillips head screw



4. Remove the (8) plastic clips



5. Remove the plastic moulding



6. Remove the front bumper



7. Remove the 10mm bolt



8. Remove the 10mm bolt



9. Remove the 10mm bolt



10. Remove the stock headlight



11. Disconnect the headlight harness



12. Disconnect the headlight harness



13. Remove the turn signal light socket



14. Remove the 10mm bolt



15. Remove the 10mm bolt



16. Remove the headlight bracket and transfer onto the projector headlight



17. Tighten the (2) 10mm bolts



18. Remove the turn signal light bulb



19. Connect the wire harness to the turn signal light socket
Please see the " L. E. D. tail lights installation instructions"
If your tail lights don't have L. E. D. You can skip the installation instructions.



20. Place the turn signal socket into the projector headlight



21. Connect the headlight harness to the projector headlight



22. Connect the headlight harness



23. Place the projector headlight in the stock location



24. Tighten the 10mm bolt



25. Tighten the 10mm bolt



26. Tighten the 10mm bolt



27. Replace the front bumper



28. Replace the plastic moulding and the (8) plastic clips



29. Tighten the phillips head screw



30. Replace the (10) plastic clips



31. Please repeat the steps in order from 1 to 30 for the opposite side. The installation is now complete