

SPEC-D *Tuning*

2011-2013 HYUNDAI ELANTRA PROJECTOR HEADLIGHTS INSTALLATION INSTRUCTIONS

If you experience any difficulties that the instruction did not cover, Please seek assistance at a local automotive shop

Please wear protection before you work on any vehicle.



An assistant is useful when removing the front bumper from your vehicle.

Please be cautious when working with the bumper or any parts belonging to the vehicle's body to prevent scratching.

Do not make direct contact with the halogen bulbs or the wire assembly until the unit has cooled down after use.

TOOLS AND SUPPLIES REQUIRED



If your Headlight is Halo type, you also need:



Wire Stripper

Wire Crimper

4 Blue Quick Splice Wire Connectors

4 Blue Male Quick Wire Connectors



4 Blue Female Quick Wire Connectors



2 Red Wires (8 inch)



2 Black Wires (8 inch)

Product Part Numbers:

2LHP-HTRA11-TM

2LHP-HTRA11JM-TM

2LHP-HTRA11G-TM



HYUNDAI ELANTRA PROJECTOR HEADLIGHTS INSTALLATION INSTRUCTIONS

If you experience any difficulties that the instruction did not cover, Please seek assistance at a local automotive shop

Please wear protection before you work on any vehicle.



An assistant is useful when removing the front bumper from your vehicle.

Please be cautious when working with the bumper or any parts belonging to the vehicle's body to prevent scratching.

Do not make direct contact with the halogen bulbs or the wire assembly until the unit has cooled down after use.



1. Before



2. (6) plastic clips location



3. Remove the (6) plastic clips



4. Remove the 10mm bolt



5. (5) plastic clips location



6. Remove the (5) plastic clips



7. Remove the front bumper



8. Disconnect the headlight harness



9. Remove the 12mm bolt



10. Remove the (2) 10mm bolts



11. Remove the headlight



12. Place the new headlight in the stock location



13. Connect the headlight harness

Please see the " L. E. D. headlights installation instructions"
If your headlights don't have L.E.D. You can skip the installation instruction.



14. Replace the front bumper



15. Replace the (5) plastic clips



16 Tighten the 10mm bolt



17. Replace the (6) plastic clips



18. Replace the (6) plastic clips
Please repeat the steps from 1 to 18 for the opposite side



19. The installation is now complete