

## 1998-2000 FORD RANGER HEADLIGHTS INSTALLATION INSTRUCTIONS

\*If you experience any difficulties that the instructions did not cover, Please seek assistance at local automotive shop.



\*An assistant is useful when removing the front bumper from your vehicle.

\*Please be cautious when working with the bumper or any parts belonging to the vehicles' body prevent scratching.

\*Do not make direct contact with the halogen bulb or the wire assembly until the unit has cooled down after use.

## TOOLS AND SUPPLIES REQUIRED

1/4" Drive Ratchet

6" Extension

1/4" Socket

Needle Nose Pliers

If your Headlight is Halo type, you also need:

Wire Stripper

Wire Crimper

4 Blue Quick Splice Wire Connectors

4 Blue Male Quick Wire Connectors

4 Blue Female Quick Wire Connectors

2 Red Wires (8 inch)

2 Black Wires (8 inch)






## 1998-2000 FORD RANGER HEADLIGHTS INSTALLATION INSTRUCTIONS

\*If you experience any difficulties that the instructions did not cover, Please seek assistance at local automotive shop.

\*Please wear protection before you work on your vehicle.



\*Please be cautious when working with the bumper or any parts belonging to the vehicles' body prevent scratching.

\*Do not make direct contact with the halogen bulb or the wire assembly until the unit has cooled down after use.



1. (2) .25 in. screws location



2. Remove the (2).25 in. screws



3. Remove the corner-bumper light



4. Disconnect the light sockets



5. Disconnect the light sockets



6. 2 retainer the clips location



7. Remove the (2) retainer clips



8. Remove the (2) retainer clips



9. Remove the stock headlight



10. Unplug the headlight bulb



11. Install the headlight bulb into the new headlight



12. Place the new headlight in the stock location



13. Replace the (2) retainer clips



14. Replace the light sockets in the corner-bumper light



15. Replace the light sockets in the corner-bumper light



16. Replace the light sockets in the corner-bumper light



17. Replace the corner bumper light



18. Tighten the (2) .25 in. screws



19. Tighten the (2) .25 in. screws



20. Please repeat the steps in order from 1 to 19 for the opposite side  $\,$ 



21. The installation is now complete

